



IMAGETEAM™ 3800, 3900, 4600, 4800, 5600, 5800 Hand Held Linear Imagers

Programming Bar Codes - Prefix, Suffix, Data Editing

Adding a Prefix or Suffix

The following are abbreviated instructions on entering a prefix or suffix. For complete instructions refer to the user's guide.

1. Scan the Add Prefix or Add Suffix Bar code.
2. Enter the Symbology Type.
3. Enter the Hex Value for the character(s) for the pre/suffix.
4. Scan Save.

Add Prefix

Begins programming sequence for adding a prefix.



Add Suffix

Begins programming sequence for adding a suffix.



Clear All Prefixes

Removes all Prefixes.



Clear all Suffixes

Removes all suffixes.



Add Code ID Prefix (Single Scan)

Adds a code id to the beginning of a bar code scan.



TAB Suffix (Single Scan)

Programs the imager to add a TAB key function after each scan.



Carriage Return Suffix (Single Scan)

Programs the imager to add an Enter key function after each scan.



Programming Bar Codes - Data Editing

Data Format Editor Instructions

The following are abbreviated instructions for entering a data format. For complete instructions refer to the user's guide.

- Step 1.** Scan the **Enter Data Format** symbol (page 5-4).
- Step 2. Primary/Alternate Format**, scan **0** for Primary Format
- Step 3. Terminal Type**, scan 099 for any terminal type
- Step 4. Code I.D.**, scan 99 for any bar code type
- Step 5. Length**, scan 9999 for any length bar code.
- Step 6. Editor Commands**
Use the Programming Chart the follows.
- Step 7.** Scan **Save** to save your entries.

Enter Data Format

Begins programming sequence for data formatting.



~ 0 1 D F M B K 3 .

Clear all Data Formats

Removes all data formats.



~ 0 1 D F M C A 3 .

IMAGETEAM™ 3800, 3900, 4600, 4800, 5600, 5800
Hand Held Linear Imagers

Programming Chart



Factory Defaults

Resets your imager to default settings.



Sample Code 39

